

ITEM	PART #	DESCRIPTION	QTY
1	M004-R40	MOTOR HOUSING	1
2	6WT-118	REAR ROTOR BEARING RETAINING NUT	1
2A	6WT-117	RETAINING NUT WASHER	1
3	DG20-22	REAR ROTOR BEARING	1
4	M004-739	REAR END PLATE GASKET	1
5	M004-12	REAR END PLATE	1
6	M004-53	ROTOR	1
7	4RL-42-5	VANE PACKET (SET OF 5)	1
8	M004-R3	CYLINDER	1
9	88V60-98	CYLINDER DOWEL	1
10	M004-11	FRONT END PLATE	1
11	M004-210	FRONT END PLATE SEAL	1
12	WWA100-97	FRONT ROTOR BEARING	1
13	M004-207	MOTOR CLAMP WASHER	1
14	M004-37	GEAR CASE	1
15	M002-95	GEAR CASE SCREW	1
16	6WTN-17	ROTOR PINION	1
17	6LN-216	GEAR HEAD	1
18	6WTM-10	GEAR HEAD PLANET GEAR	1
19	6WTM-500	PLANET GEAR BEARING	1
20	6WTN-A10	GEAR HEAD PLANET GEAR ASSEMBLY	1
21	7AH-500	PLANET GEAR BEARING	1
22	6LM-80	GEAR HEAD SPACER	1
23	M004-316-083	INTERMEDIATE GEAR HEAD	1
24	6WTN-A10	GEAR HEAD PLANET GEAR ASSEMBLY	1
25	7AH-500	PLANET GEAR BEARING	1
26	6LM-80	GEAR HEAD SPACER	1
27	M004-108-011	SPINDLE	1
28	6WTM-10	SPINDLE PLANET GEAR	1
29	6WTM-500	PLANET GEAR BEARING	1
30	6WTN-A10	SPINDLE PLANET GEAR ASSEMBLY	1
31	7AH-500	PLANET GEAR BEARING	1
33	M004-27	COUPLING NUT	1
34	M004-29	COUPLING NUT RETAINER	1
35	M004-510	SPINDLE BEARING	1
36	M004-111	SPINDLE BEARING SPACER	1
37	RX3-729	SPINDLE RETAINING RING	1
38	M004-210	GEAR CASE SEAL	1
39	M004-580	FLANGE	1

Sheet1

40	M004-210	FLANGE SEAL	1
41	M004-271	SPINDLE SEAL	1
42	M002-561	FLANGE KEY	1