

Walcut Model 30E

Walcut Model 30E Frame Breakdown- parts List - pg 1/2

| ITEM | PART | QTY. | DESCRIPTION |
|------|------|------|---|
| # | # | REQ. | |
| 0 | 3000 | 1 | Eccentric wrench |
| 1 | 3001 | 8 | 3/4" camfollower |
| 2 | 3002 | 8 | Gitts grease fitting |
| 3 | 3003 | 8 | 7/8" camfollower |
| 4 | 3004 | 10 | Alemite grease fitting |
| 5 | 3005 | 22 | 1/4-20x.375 Heli-coil |
| 6 | 3006 | 20 | 1/4-20x3/8 socket set screw (Length varies, specify 1/4,3/8,1/2,5/8 or 3/4) |
| 7 | 3007 | 4 | 3/8-24x.375 Heli-coil |
| 8 | 3008 | 17 | 5/16-18x.0469 Heli-coil |
| 9 | 3009 | 12 | Eccentric washer |
| 10 | 3010 | 12 | 3/8-24 jam nut |
| 11 | 3011 | 12 | Eccentric bushing |
| 12 | 3012 | 4 | 3/4-16x1 1/2 hex head cap screw |
| 13 | 3013 | 4 | Column washer |
| 14 | 3014 | 1 | Base |
| 15 | 3015 | 4 | Camfollower washer |
| 16 | 3016 | 8 | 10-24x/8 socket flat head machine screw |
| 17 | 3017 | 4 | Wear plate |
| 18 | 3018 | 4 | 1/4x1" roll pin |
| 19 | 3019 | 13 | 5/16-18x7/8 hex head cap screw |
| 21 | 3021 | 2 | 1/4x1 1/2 roll pin |
| 22 | 3022 | 1 | 5/16-18x1 1/4 hex head cap screw |
| 23 | 3023 | 1 | 5/16-18 x1 1/2 hex head cap screw |
| 24 | 3024 | 4 | Camfollower cover |
| 25 | 3025 | 2 | 1/4-20x3/8 slotted set screw |
| 26 | 3026 | 2 | 1/4-20x.625 Heli-coil |
| 29 | 3029 | 2 | Column |
| 30 | 3030 | 1 | Carriage |
| 31 | 3031 | 4 | Grease fitting |
| 32 | 3032 | 2 | Male blade guard holder |
| 33 | 3033 | 4 | Column seal |

Walcut Model 30E

Walcut Model 30E Frame Assembly- parts List - pg 2/2

| | | | |
|-----|-------|---|----------------------------------|
| 33 | 3033 | 4 | Column seal |
| 34 | 3034 | 4 | Column bushing |
| 36 | 3036 | 1 | Side brace (left) |
| 36A | 3036A | 1 | Side brace (right) |
| 37 | 3037 | 1 | Top plate |
| 42 | 3042 | 1 | Depth nut |
| 43 | 3043 | 1 | 3/4-10x9 1/8 threaded rod |
| 44 | 3044 | 4 | 1/4-20x3/4 socket head cap screw |
| 45 | 3045 | 1 | Depth screw |
| 46 | 3046 | 1 | Depth control handle |
| 47 | 3047 | 1 | 1/4 USS washer |
| 48 | 3048 | 1 | 1/4-20x5/8 hex head cap screw |
| 82 | 3082 | 1 | Blade spindle seal |
| 84 | 3084 | | Hub spacer (as required) |
| 85 | 3085 | 1 | Hub |
| 86 | 3086 | 1 | Hub cap |
| 87 | 3087 | 1 | 3/8 washer |
| 88 | 3088 | 1 | 3/8-16x1 1/4 hex head cap screw |
| 133 | 30133 | 8 | 10-24x.190 Heli-coil |